

# Sensory Swing Installation Checklist

Use this checklist to safely install a sensory swing at home. Each step helps ensure proper support, safety, and usability for your child's sensory needs.

## ***Preparation***

- ✓ Choose a safe location with 3–4 feet clearance in all directions
- ✓ Confirm ceiling height (at least 7 ft recommended)
- ✓ Identify ceiling joists or concrete structure
- ✓ Verify weight rating of all swing components (minimum 300–500 lbs recommended)

## ***Tools & Hardware***

- ✓ Stud finder
- ✓ Drill and pilot bit
- ✓ Heavy-duty swing hanger or ceiling mount
- ✓ Lag screws or concrete anchors
- ✓ Swivel attachment (optional for 360° motion)
- ✓ Locking carabiners and daisy chains/straps
- ✓ Ladder and pencil for marking

## ***Installation Steps***

- ✓ Locate and mark center of ceiling joist
- ✓ Drill pilot holes slightly smaller than lag screw
- ✓ Attach hanger securely using all provided fasteners
- ✓ Test mount by applying gradual bodyweight pressure
- ✓ Connect swing via carabiners and check swivel rotation
- ✓ Ensure swing hangs at proper height (adjust straps as needed)

## ***Final Safety Checks***

- ✓ Confirm all bolts and straps are secure
- ✓ Swing rotates and moves freely without obstruction
- ✓ Hardware shows no signs of cracking, rust, or movement
- ✓ Schedule routine inspection every 3–6 months